



With hazard switch on, the terminals 4, 6, 7 & 9 are connected together.

There are a few discrepancies between the pre HE ROM circuit diagram wire colours and some colours on my 1979 car.

PRE-HE XJ-S INDICATOR & HAZARD CIRCUIT