


FIG 24.1



Terminal	Description
1	ECU GROUND
2	THROTTLE POT. GROUND SIGNAL
3	THROTTLE POT. POSITIVE
4	AIR TEMP. SIGNAL
5	O2 SENSOR INTEGRATE
6	MAIN FEED. TEMP. SIGNAL
7	O2 SENSOR BANK A
8	O2 SENSOR BANK B
9	SHIELD
10	FUEL TEMP. SWITCH
11	START SIGNAL
12	BANK B INJECTORS "ON"
13	BANK A INJECTORS "ON"
14	BANK A INJECTORS "ON"
15	BANK A INJECTORS "ON"
16	FUEL PUMP RELAY
17	INJECTOR GROUNDS
18	INJECTOR GROUNDS
19	INJECTOR GROUNDS
20	ENGINE SPEED SIGNAL
21	START RELAY
22	PUMP RELAY
23	START RELAY
24	FUEL PUMP
25	FUEL PUMP
26	SOLENOID VACUUM VALVE
27	PURGE CONTROL VALVE
28	PURGE CONTROL VALVE
29	PURGE CONTROL VALVE
30	SUPPLEMENTARY AIR VALVE
31	SUPPLEMENTARY AIR VALVE
32	45 SECOND TIMER
33	NEUTRAL SWITCH
34	AMPLIFIER