

## AIR Temperature Sensor - XJ – XJS V12 HE

<b>Temperature</b>	<b>Resistance</b>
-10°C	9.1 - 9.3 kOhm
0°C	5.7 – 5.9 kOhm
10°C	3.7 kOhm
20°C	2.4 – 2.6 kOhm
30°C	1.7 kOhm
40°C	1.1 – 1.3 kOhm
50°C	830 Ohm
60°C	500 – 700 Ohm