

TESTING

FAULT-FINDING CHART

Starter solenoid will not operate with selector lever in any position.




FIG. 72.

